



# CB-2617

Micro-ATX Industrial Motherboard  
User's Manual

## Copyright

This publication contains information that is protected by copyright. No part of it may be reproduced in any form or by any means or used to make any transformation/adaptation without the prior written permission from the copyright holders.

This publication is provided for informational purposes only. The manufacturer makes no representations or warranties with respect to the contents or use of this manual and specifically disclaims any express or implied warranties of merchantability or fitness for any particular purpose. The user will assume the entire risk of the use or the results of the use of this document. Further, the manufacturer reserves the right to revise this publication and make changes to its contents at any time, without obligation to notify any person or entity of such revisions or changes.

Changes after the publication's first release will be based on the product's revision. The website will always provide the most updated information.

© 2025. All Rights Reserved.

## Trademarks

Product names or trademarks appearing in this manual are for identification purpose only and are the properties of the respective owners.

## FCC and DOC Statement on Class B

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio TV technician for help.

## Notice:

1. The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
2. Shielded interface cables must be used in order to comply with the emission limits.

# Table of Contents

Chapter 1 - Introduction.....	6
Specifications .....	6
Block Diagram .....	8
Dimension.....	8
Chapter 2 - Hardware Installation.....	9
Board Layout.....	9
Top View.....	9
Installing the heat sink.....	11
Installing the Heat Sink.....	11
Jumper Settings .....	12
LPC/ESPI Mode Select (J61) .....	12
Clear CMOS (J6).....	12
COM2 (J73).....	13
Clear CMOS (J6).....	13
COM1 (J55 & J64 ) .....	14
BMC Select (J46).....	14
Chassis Anti-theft (J42) .....	15
SATA DOM Select (J_DOM1).....	15
Pin Assignment .....	16
Power On (J_PB1) .....	16
Reset (J_RST1) .....	16
CPU I2C (J52) .....	17
CPU I2C (J67) .....	17
CPU I2C (J65) .....	18
CPU I2C (J66) .....	18
CPU Test (J70).....	19
CPU Test (J36).....	19
UART (J51).....	20
CPU NTEST (J38) .....	20
UART Debug (J44).....	21
UART Debug (J8).....	21
UART Debug (J63).....	22
UART Debug (J50).....	22
CPU Fan (J54).....	23
CPU Temperature Monitor (J35).....	23
System Fan1~3 (J56/J57/J72).....	24
LAN LED (J_LAN_LED1).....	24
SMBus (J_PMB1).....	25
CPU Clock Drive (J60).....	25
BIOS ROM (J59).....	26
COM2 (COM2).....	26
JTAG CPLD (J43) .....	27
USB2.0 (F_USB2_1) .....	27
Front Panel (F_PANEL1).....	28
TPM (J_TPM1).....	28
CPU Test (J10) .....	29
VGA (J_VGA1).....	29
GPIO (J_GPIO1).....	30
USB3.0 (F_USB3_1) .....	31
CPU Debugging (J9).....	32
System Memory .....	33
Installing the SO-DIMM Module .....	33
Expansion Slots.....	34
Installing the M.2 Module .....	34

## About this Manual

This manual can be downloaded from the website.

The manual is subject to change and update without notice, and may be based on editions that do not resemble your actual products. Please visit our website or contact our sales representatives for the latest editions.

## Warranty

1. Warranty does not cover damages or failures that occur from misuse of the product, inability to use the product, unauthorized replacement or alteration of components and product specifications.
2. The warranty is void if the product has been subjected to physical abuse, improper installation, modification, accidents or unauthorized repair of the product.
3. Unless otherwise instructed in this user's manual, the user may not, under any circumstances, attempt to perform service, adjustments or repairs on the product, whether in or out of warranty. It must be returned to the purchase point, factory or authorized service agency for all such work.
4. We will not be liable for any indirect, special, incidental or consequential damages to the product that has been modified or altered.

## Static Electricity Precautions

It is quite easy to inadvertently damage your PC, system board, components or devices even before installing them in your system unit. Static electrical discharge can damage computer components without causing any signs of physical damage. You must take extra care in handling them to ensure against electrostatic build-up.

1. To prevent electrostatic build-up, leave the system board in its anti-static bag until you are ready to install it.
2. Wear an antistatic wrist strap.
3. Do all preparation work on a static-free surface.
4. Hold the device only by its edges. Be careful not to touch any of the components, contacts or connections.
5. Avoid touching the pins or contacts on all modules and connectors. Hold modules or connectors by their ends.



### Important:

Electrostatic discharge (ESD) can damage your processor, disk drive and other components. Perform the upgrade instruction procedures described at an ESD workstation only. If such a station is not available, you can provide some ESD protection by wearing an antistatic wrist strap and attaching it to a metal part of the system chassis. If a wrist strap is unavailable, establish and maintain contact with the system chassis throughout any procedures requiring ESD protection.

## Safety Measures

- To avoid damage to the system, use the correct AC input voltage range.
- To reduce the risk of electric shock, unplug the power cord before removing the system chassis cover for installation or servicing. After installation or servicing, cover the system chassis before plugging the power cord.

## About the Package

The package contains the following items. If any of these items are missing or damaged, please contact your dealer or sales representative for assistance.

- 1 CB-2617 motherboard
- 1 I/O shield

The board and accessories in the package may not come similar to the information listed above. This may differ in accordance with the sales region or models in which it was sold. For more information about the standard package in your region, please contact your dealer or sales representative.

## Before Using the System Board

When installing the system board in a new system, you will need at least the following internal components.

- Memory module
- Storage device such as a hard disk drive.
- Power supply

External system peripherals may also be required for navigation and display, including at least a keyboard, a mouse and a video display monitor.


## Chapter 1 - Introduction

### ► Specifications


SYSTEM	Processor	HYGON C86-4G 3490 Processor Series
	Memory	Four UDIMM up to 128GB Dual Channel DDR5 up to 5200 MHz
	BIOS	Byosoft BIOS
	BMC	ASPEED AST2600 (IPMI 2.0 support)
GRAPHICS	Display	1 x VGA (DB15) 1 x VGA (opt. pin header share Rear IO VGA) VGA: resolution up to 1920x1200 @ 60Hz
EXPANSION	Interface	1 x PCIe x16 (Gen 4) (1 x16 signals or 1 x8 signals) 1 x PCIe x8 (Gen 4) (N/A or 1 x8 signals) --Support PCIe1/PCIE2 : single at x16(PCIE1)/NA(PCIE4) --Support PCIe1/PCIE4 : dual at x8(PCIE1)/x8(PCIE4) 2 x PCIe x8 (Gen 4) (2 x4 signals)
		1 x M.2 2280 M key (SATA or PCIe Gen4 x4 support) (SATA signal share M.2, PCIE x4 signal share PCIE#3 x8 slot) 1 x MINI-PCIE (PCIe/USB 2.0/WIFI/Bluetooth support)
ETHERNET	Controller	1 x Realtek® RTL8211FS (IPMI support) 2 x Intel® I210AT
REAR I/O	Ethernet	2 x 1GbE (RJ-45) 1 x IPMI LAN (RJ-45)
	Serial	1 x COM1 RS232 (DB9)
	USB	2 x USB 3.2 Gen1 2 x USB 2.0
	Display	1 x VGA (DB15)
INTERNAL I/O	Serial	1 x COM2 RS232 Header
	USB	4 x USB 3.2 Gen1 2 x USB 2.0
	SATA	3 x SATA 3.0 (up to 6Gb/s) 1 x M.2 (opt.)
	DIO	8, GPIO
	LED	1 x BMC LED 1 x System power LED 1 x Power button LED
WATCHDOG TIMER	Output & Interval	System Reset, Programmable via Software from 1 to 255 Seconds
SECURITY	TPM	TPM 2.0

POWER	Type	ATX
	Connector	8-pin ATX 12V power 24-pin ATX power
	RTC Battery	CR2032 Coin Cell
OS SUPPORT	Microsoft	Windows 10/11 64bit Kylin OS
	Linux	Linux
ENVIRONMENT	Temperature	Operating: 0 to 60°C Storage: -20 to 75°C
	Humidity	Operating: 5 to 95% RH (No condensation)
MECHANISM	Dimensions	microATX Form Factor 243.8mm x 243.8mm
	Height	PCB: 1.6mm Top Side: < 19.0mm Bottom Side: < 4.0mm

► Block Diagram




► Dimension



# Chapter 2 - Hardware Installation

## ► Board Layout

Top View



- |                            |                                  |
|----------------------------|----------------------------------|
| 1 ATX Power                | 21 CPU I2C                       |
| 2 System Fan1              | 22 CPU I2C                       |
| 3 System Fan2              | 23 Clear CMOS                    |
| 4 USB3.0                   | 24 LPC/ESPI Mode Select          |
| 5 USB 3.0 Type A           | 25 CPU Test                      |
| 6 USB 3.0 Type A           | 26 CPU Test                      |
| 7 CPU Debugging            | 27 BIOS ROM                      |
| 8 Power On                 | 28 SPI Flash BIOS                |
| 9 Reset                    | 29 Buzzer                        |
| 10 USB2.0                  | 30 TPM                           |
| 11 System Fan1             | 31 UART                          |
| 12 +12V Power              | 32 SATA3                         |
| 13 CPU Temperature Monitor | 33 SATA4                         |
| 14 CPU NTEST               | 34 SATA2                         |
| 15 DIMM1                   | 35 SATA1                         |
| 16 DIMM2                   | 36 CPU Clock Drive               |
| 17 DIMM3                   | 37 PCIe Gen4 x16 or PCIe Gen4 x8 |
| 18 DIMM4                   | 38 PCIe Gen4 x4                  |
| 19 CPU Fan                 | 39 PCIe Gen4 x4                  |
| 20 CPU I2C                 | 40 PCIe Gen4 x8                  |

41	JTAG CPLD	55	USB3.0
42	UART Debug	56	LAN1
43	UART Debug	57	LAN2
44	SMBus	58	VGA
45	CPU Test	59	UART Debug
46	LAN LED	60	VGA
47	Front Panel	61	Power Button
48	GPIO	62	BMC Select
49	COM2	63	Chassis Anti-theft
50	UART Debug	64	COM2
51	COM1	65	SATA DOM Select
52	COM1	66	CPU I2C
53	COM1 DB9		
54	▲LAN ▼USB2.0		

## ► Installing the heat sink


### Installing the Heat Sink

The CPU must be kept cool by using a heat sink, otherwise the CPU will overheat damaging both the CPU and system board.

1. Before you install the fan / heat sink, you must apply a thermal paste onto the top of the CPU. The thermal paste is usually supplied when you purchase the fan / heat sink assembly. Do not spread the paste all over the surface. When you later place the heat sink on top of the CPU, the compound will disperse evenly.


Some heat sinks come with a patch of preapplied thermal paste. Do not apply thermal paste if the fan / heat sink already has a patch of thermal paste on its underside. Peel the strip that covers the paste before you place the fan / heat sink on top of the CPU.

2. Place the heat sink on top of the CPU. The 4 spring screws around the heat sink, which are used to secure the heat sink onto the system board, must match the 4 mounting holes around the board.
3. Screw tight two of the spring screws at opposite corners into the mounting holes. And then proceed with the other two spring screws.



► Jumper Settings

LPC/ESPI Mode Select (J61)




■ 1-2 On: LPC (Default)



■ 2-3 On: ESPI

Clear CMOS (J6)




■ 1-2 On: Normal (Default)



■ 2-3 On: Clear CMOS Data

### COM2 (J73)




■ 1-2 Off



■ 2-3 On (Default)

### Clear CMOS (J6)




■ 1-2 On: Normal (Default)




■ 2-3 On: Clear CMOS Data

### COM1 (J55 & J64 )




■ 1-2 Off



■ 2-3 On (Default)

### BMC Select (J46)




■ 1-2 On: On (Default)



■ 2-3 On: Off

Chassis Anti-theft (J42)




■ 1-2 Off: Connected



■ 1-2 On: Disconnected

SATA DOM Select (J\_DOM1)




■ 1-2 On



■ 2-3 Off


► **Pin Assignment**

Power On (J\_PB1)




Pin	Assignment
1	Power On+
2	Power On-

Reset (J\_RST1)




Pin	Assignment
1	Reset+
2	PWM

CPU I2C (J52)




Pin	Assignment
1	SCL
2	SDA
3	GND

CPU I2C (J67)




Pin	Assignment
1	SCL
2	SDA
3	GND

CPU I2C (J65)




Pin	Assignment
1	SCL
2	SDA
3	GND

CPU I2C (J66)




Pin	Assignment
1	SCL
2	SDA
3	GND

CPU Test (J70)




Pin	Assignment
1	FM_MFG_MODE_N
2	I2C_P0_PDCTL_INT
3	GND

CPU Test (J36)




Pin	Assignment
1	SCL
2	SDA
3	GND

UART (J51)




Pin	Assignment
1	UART0_RTS
2	UART0_CTS
3	GND

CPU NTEST (J38)




Pin	Assignment
1	NTEST_TXD
2	NTEST_RXD
3	GND

UART Debug (J44)





Pin	Assignment
1	UART_BMC_HDR_TXD
2	UART_BMC_HDR_RXD
3	GND

UART Debug (J8)





Pin	Assignment
1	UART_COM_TXD
2	UART_COM_RXD
3	GND

UART Debug (J63)




Pin	Assignment
1	CPU_UART_DEBUG_TXD
2	CPU_UART_DEBUG_RXD
3	GND

UART Debug (J50)




Pin	Assignment
1	UART1_CTS
2	UART1_RTS
3	GND

CPU Fan (J54)




Pin	Assignment
1	GND
2	VCC12
3	FAN Speed Detection
4	FAN Speed Control

CPU Temperature Monitor (J35)




Pin	Assignment
1	OVERTEMP
2	CPU_TEMP_MON_SCL
3	CPU_TEMP_MON_SDA
4	GND

System Fan1~3 (J56/J57/J72)




Pin	Assignment
1	GND
2	VCC12
3	FAN Speed Detection
4	FAN Speed Control

LAN LED (J\_LAN\_LED1)




Pin	Assignment	Pin	Assignment
1	P3V3_AUX	2	LKACT#_LAN2
3	P3V3_AUX	4	LKACT#_LAN3

SMBus (J\_PMB1)




Pin	Assignment
1	SCL
2	SDA
3	ALERT
4	GND
5	VCC3.3

CPU Clock Drive (J60)




Pin	Assignment
1	SCL
2	SDA
3	P0_VDD_33_S5
4	CPLD_SLT_THERMTRIP-
5	N/C
6	GND

BIOS ROM (J59)




Pin	Assignment	Pin	Assignment
1	VCC1.8	2	GND
3	SPI_BIOS_ROM_CS_N	4	SPI_BIOS_ROM_CLK
5	SPI_BIOS_ROM_DI	6	SPI_BIOS_ROM_DO
7	NC	8	R_SPI_FLASH_RST_N

COM2 (COM2)




Pin	Assignment	Pin	Assignment
1	VCC5	2	N/C
3	RXD	4	RTS
5	TXD	6	CTS
7	N/C	8	N/C
9	GND	10	---

### JTAG CPLD (J43)




Pin	Assignment	Pin	Assignment
1	TCK	2	N/C
3	TMS	4	GND
5	TDI	6	VCC3.3
7	TDO	8	N/C
9	N/C	10	VCC3.3

### USB2.0 (F\_USB2\_1)




Pin	Assignment	Pin	Assignment
1	VCC5	2	VCC5
3	USB2.0_1-	4	USB2.0_2-
5	USB2.0_1+	6	USB2.0_2+
7	GND	8	GND
9	---	10	N/C

### Front Panel (F\_PANEL1)




Pin	Assignment	Pin	Assignment
1	HDD LED+	2	Power LED+
3	HDD LED-	4	Power LED-
5	Reset-	6	Power ON+
7	Reset+	8	Power ON-
9	N/C	10	---

### TPM (J\_TPM1)




Pin	Assignment	Pin	Assignment
1	VCC3.3	2	SPI_CS2
3	TPM_PLT_RST	4	SPI_MISO_TPM
5	SPI_CLK_TPM	6	GND
7	SPI_MOSI_TPM	8	---
9	N/C	10	SPI_TPM_RIRQ

CPU Test (J10)




Pin	Assignment	Pin	Assignment
1	CPU_BP4	2	CPU_BP0
3	CPU_BP5	4	CPU_BP1
5	CPU_BP6	6	CPU_BP2
7	N/C	8	N/C
9	N/C	10	N/C

VGA (J\_VGA1)



Pin	Assignment	Pin	Assignment
1	SCL	7	GND
2	SDA	8	RED
3	GND	9	GND
4	BLUE	10	HSYNC
5	GND	11	VSYNC
6	GREEN	12	ON


GPIO (J\_GPIO1)



Pin	Assignment	Pin	Assignment
1	VCC_GPIO <sup>[note]</sup>	2	GPIO_R_4
3	GPIO_R_0	4	GPIO_R_5
5	GPIO_R_1	6	GPIO_R_6
7	GPIO_R_2	8	GPIO_R_7
9	GPIO_R_3	10	----
11	GND	12	GND


**Notes:**  
 Power on this Pin is 5V by default, 3.3V is available if specified. (resistor selectable)

USB3.0 (F\_USB3\_1)




Pin	Assignment	Pin	Assignment
1	VCC5	11	USB2.0_2+
2	USB3.0_RX1-	12	USB2.0_2-
3	USB3.0_RX1+	13	GND
4	GND	14	USB3.0_TX2+
5	USB3.0_TX1-	15	USB3.0_TX2-
6	USB3.0_TX1+	16	GND
7	GND	17	USB3.0_RX2+
8	USB2.0_1-	18	USB3.0_RX2-
9	USB2.0_1+	19	GND
10	N/C	20	---

CPU Debugging (J9)



Pin	Assignment	Pin	Assignment
1	P0_VDD_18_S5	2	TCK
3	GND	4	TMS
5	GND	6	TDI
7	GND	8	TDO
9	HDT_HDR_TRST_R_N	10	PWROK
11	N/C	12	RESET_N
13	N/C	14	N/C
15	N/C	16	DBREQ_R_N
17	HDT_PRESENT_N	18	N/C
19	P0_VDD_18_S5	20	N/C

► **System Memory**




- 1 DIMM1
- 2 DIMM2
- 3 DIMM3
- 4 DIMM4

**Installing the SO-DIMM Module**

Before installing the memory module, please make sure that the following safety cautions are well-attended.

1. Make sure the PC and all other peripheral devices connected to it has been powered down.
2. Disconnect all power cords and cables.
3. Locate the SO-DIMM socket on the system board
4. Make sure the notch on memory card is aligned to the key on the socket.



The system board supports the following memory interface.


**Single Channel (SC)**

Data will be accessed in chunks of 64 bits from the memory channels. DIMMs are on the same channel. DIMMs in a channel can be identical or completely different. However, we highly recommend using identical DIMMs. Not all slots need to be populated.

**Dual Channel (DC)**

Data will be accessed in chunks of 128 bits from the memory channels. Dual channel provides better system performance because it doubles the data transfer rate.

## ► Expansion Slots




1 M.2 M1-Key


### Installing the M.2 Module

Before installing the M.2 module into the M.2 socket, please make sure that the following safety cautions are well-attended.


1. Make sure the PC and all other peripheral devices connected to it has been powered down.
2. Disconnect all power cords and cables.
3. Locate the M.2 socket on the system board
4. Make sure the notch on card is aligned to the key on the socket.
5. Make sure the standoff screw is removed from the standoff.




Please follow the steps below to install the card into the socket.



**Step 1:**  
Insert the card into the socket at an angle while making sure the notch and key are perfectly aligned.



**Step 2:**  
Press the end of the card far from the socket down until against the stand-off.



**Step 3:**  
Screw tight the card onto the stand-off with a screw driver and a stand-off screw until the gap between the card and the stand-off closes up. The card should be lying parallel to the board when it's correctly mounted.