


# PT332-DRM



USB Power: 0-3 (JP2), 4-7 (JP3), 8-11 (JP7)	
5V (default)	1-2 On
5V_standby	2-3 On

PS/2 Power	JP4
5V (default)	1-2 On
5V_standby	2-3 On

Flash BIOS	J5
Flash System & ME BIOS	1-2 On
Flash System BIOS	1-2 Off

Clear CMOS Data	JP1
Normal (default)	1-2 On
Clear CMOS Data	2-3 On

Power-on Select	JP6
Power-on via power button (default)	1-2 On
Power-on via AC power; Power-on via WOL After G3	2-3 On