



Clear CMOS Data	JP9
Normal (default)	1-2 On
Clear CMOS Data	2-3 On

USB Power Select: 1-2 (JP5), 2-3/8/10-11 (JP8), 3-4 (JP6),	
+5V (default)	1-2 On
+5V_standby	2-3 On

USB 4-5 Power Select	JP15
+5V (default)	2-4 On
+5V_standby	4-6 On

PS/2 Keyboard/Mouse Power Select	JP15
+5V (default)	1-3 On
+5V_standby	3-5 On

COM 10 RS232/422/485 Select	JP2
RS232 (default)	1-2 On
RS422 Full Duplex	3-4 On
RS485	5-6 On

SATA DOM Power Select	JP11
GND (default)	1-2 On
+5V	2-3 On

COM 10 RS232/422/485 Select	JP17, JP18
RS232 (default)	1-3, 2-4 On
RS422 Full Duplex/RS485	3-5, 4-6 On

COM 10 RS232/Power Select	JP14
RS232 (default)	1-3 (RI), 2-4 (DCD) On
RS232 with power	3-5 (+5V), 4-6 (+12V) On

Power-on Select	JP10
Power-on via power button (default)	1-2 On
Power-on via AC power; Power-on via WOL after G3	2-3 On

Note:

1. HD332-H81B has LAN 1 only.
2. HD332-H81B: 2 COM (COM 1 and COM 2).
HD332-H81X: 10 COM (COM 1 to COM 10).
3. When COM 10 RS232/422/485 is selected, JP17 and JP18 must be set in accordance to JP2.
4. SATA 1 supports SATA DOM.

Battery Notice



Battery Usage

The lithium ion battery powers the real-time clock and CMOS memory. It is an auxiliary source of power when the main power is shut off.



Safety Measures

- Danger of explosion if battery incorrectly replaced.
- Replace only with the same or equivalent type recommend by the manufacturer.
- Dispose of used batteries according to local ordinance.



Mesure de Sécurité de l'usage de Batterie

Batterie:

- Danger d'explosion si la batterie n'est pas correctement remplacée.
- Remplacez seulement avec le même type ou équivalent recommandé par le fabricant.
- Traitez des batteries usées selon le règlement local.