



Clear CMOS Data	JP1
Normal (default)	1-2 On
Clear CMOS Data	2-3 On

Auto Power-on Select	JP5
Power-on via power button (default)	1-2 On
Power-on via AC power	2-3 On

Backlight Power Select	JP3
+3.3V (default)	1-2 On
+5V	2-3 On

RS232/Power Select	JP9 (COM 1) JP14 (COM 2)
RS232 (default)	1-3 (RI-), 2-4 (DCD-) On
RS232 with power	3-5 (+5V), 4-6 (+12V) On

Panel Power Select	JP2
+12V	1-2 On
+5V	3-4 On
+3.3V (default)	5-6 On

RS232/422/485 Select	JP7 (COM 1) JP11 (COM 2)	JP8/JP10 (COM 1) JP12/JP13 (COM 2)
RS232 (default)	1-2 On	1-3, 2-4 On
RS422 Full Duplex	3-4 On	3-5, 4-6 On
RS485	5-6 On	3-5, 4-6 On

LCD/Inverter Power Select	JP4
+12V (default)	1-2 On
+5V	2-3 On

Note:

- When COM 1 RS232/422/485 is selected, JP8 and JP10 must be set in accordance to JP7.
- When COM 2 RS232/422/485 is selected, JP12 and JP13 must be set in accordance to JP11.

Battery Notice



Battery Usage

The lithium ion battery powers the real-time clock and CMOS memory. It is an auxiliary source of power when the main power is shut off.



Safety Measures

- Danger of explosion if battery incorrectly replaced.
- Replace only with the same or equivalent type recommended by the manufacturer.
- Dispose of used batteries according to local ordinance.



Mesure de Sécurité de l'usage de Batterie

Batterie:

- Danger d'explosion si la batterie n'est pas correctement remplacée.
- Remplacez seulement avec le même type ou équivalent recommandé par le fabricant.
- Traitez des batteries usées selon le règlement local.