



<b>Clear CMOS Data</b>	<b>JP7</b>
Normal (default)	1-2 On
Clear CMOS Data	2-3 On
<b>LVDS Panel Power Select</b>	<b>JP8</b>
+12V	1-2 On
+5V	3-4 On
+3.3V (default)	5-6 On
<b>LCD/Inverter Power Select</b>	<b>JP9</b>
+12V (default)	1-2 On
+5V	2-3 On
<b>LVDS Backlight Power Select</b>	<b>JP10</b>
+3.3V (default)	1-2 On
+5V	2-3 On
<b>SATA 1/mSATA Signal Select</b>	<b>JP5</b>
SATA 1	1-4-7-10 2-5-8-11 On
mSATA (default)	2-5-8-11 3-6-9-12 On

<b>COM 1 RS232/Power Select</b>	<b>JP4</b>
RS232 (default)	1-3 (RI), 2-4 (DCD) On
RS232 with power	3-5 (+5V), 4-6 (+12V) On

<b>eDP Panel Power Select (optional)</b>	<b>JP1</b>
+12V	1-2 On
+5V	3-4 On
+3.3V (default)	5-6 On

<b>eDP Inverter Power Select (optional)</b>	<b>JP2</b>
+12V (default)	1-2 On
+5V	2-3 On

<b>eDP Backlight Power Select (optional)</b>	<b>JP3</b>
+3.3V (default)	1-2 On
+5V	2-3 On

<b>Auto Power-on Select</b>	<b>JP6</b>
Power-on via power button (default)	1-2 On
Power-on via AC power	2-3 On

**Note:**

1. BW171: Single 12V +/-10% DC.
2. BW173: Wide Range 15~36V.
3. The eDP connector is optional. Please contact your sales representative for more information.
4. JP1, JP2 an JP3 will work when the eDP connector is populated on the system board.

## Battery Notice

---



### Battery Usage

The lithium ion battery powers the real-time clock and CMOS memory. It is an auxiliary source of power when the main power is shut off.



### Safety Measures

- Danger of explosion if battery incorrectly replaced.
- Replace only with the same or equivalent type recommend by the manufacturer.
- Dispose of used batteries according to local ordinance.



### Mesure de Sécurité de l'usage de Batterie

Batterie:

- Danger d'explosion si la batterie n'est pas correctement remplacée.
- Remplacez seulement avec le même type ou équivalent recommandé par le fabricant.
- Traitez des batteries usées selon le règlement local.