



PS/2 Keyboard/Mouse Power Select	JP1
+5V (default)	1-2 On
+5V_standby	2-3 On
Clear CMOS Data	JP9
Normal (default)	1-2 On
Clear CMOS Data	2-3 On
USB Power Select: 0-1 (JP5), 2 (JP8), 4-5 (JP6), 8-9/10-11 (JP4)	
+5V (default)	1-2 On
+5V_standby	2-3 On
Digital I/O Power Select	JP13
+5V_standby (default)	1-2 On
+5V	2-3 On
Digital I/O Output State: DIO 3/5/7/9 (JP12), DIO 11/13/15/17 (JP7)	
+5V or +5V_standby (default)	1-2 On
GND	2-3 On
SATA DOM Power Select	JP11
GND (default)	1-2 On
+5V	2-3 On

Power-on Select	JP10
Power-on via Power Button (default)	1-2 On
Power-on via AC Power; Power-on via WOL After G3	2-3 On
COM 8 RS232/422/485 Select	JP2
RS232 (default)	1-2 On
RS422 Full Duplex	3-4 On
RS485	5-6 On
COM 8 RS232/422/485 Select	JP17/JP18
RS232 (default)	1-3, 2-4 On
RS422 Full Duplex/RS485	3-5, 4-6 On
COM 8 RS232/Power Select	JP14
RS232 (default)	1-3 (RI), 2-4 (DCD) On
RS232 with power	3-5 (+5V), 4-6 (+12V) On

Note:

1. SATA 0 supports SATA DOM.
2. When COM 8 RS232/422/485 is selected, JP17 and JP18 must be set in accordance to JP2.
3. The vertical USB (USB 2) co-lays with a USB pin header (USB 2-3) on the system board.

Battery Notice



Battery Usage

The lithium ion battery powers the real-time clock and CMOS memory. It is an auxiliary source of power when the main power is shut off.



Safety Measures

- Danger of explosion if battery incorrectly replaced.
- Replace only with the same or equivalent type recommend by the manufacturer.
- Dispose of used batteries according to local ordinance.



Mesure de Sécurité de l'usage de Batterie

Batterie:

- Danger d'explosion si la batterie n'est pas correctement remplacée.
- Remplacez seulement avec le même type ou équivalent recommandé par le fabricant.
- Traitez des batteries usées selon le règlement local.